

Energy Saving Tips

Set thermostat on a/c between 75-78 degrees

Clean or replace a/c filters every month

Set water heater to 115-120 degrees

Wash clothes in cold water

Hang clothes to dry instead of using dryer

Use Microwave to cook whenever possible

Use Compact Fluorescent Light bulbs

Use dishwasher in energy saver mode with dryer off

Wash dishes in double sink/tub if you do not have washer

Use natural light whenever possible

Use task lighting instead of whole room lighting

Cook food on stove at one time instead of all day

Cover pots and pans with lids

Match pan size to burner

Set refrigerator to 38-40 degrees

Keep the coils on refrigerator clean

Keep your freezer full even if just with water bottles

Seal up cracks in windows, doors, and walls with caulk

Use shower heads with 2.5 gpm or less of flow

Use faucet aerators

Think about how much energy is being used at all times